9/2022 Page 1/2



Kiilto Pro Odor Stop

Biological odor control









Application

Kiilto Odor Stop is an effective solution for odor control in veterinary, public and transportation facilities, nursing homes, gymnasiums, gateways, waste bins, etc.

Product properties

Kiilto Odor Stop is a biological odor control product. It removes odors caused by organic dirt. Product is based on powerful bacterial spores. Due to the nature of the spores odor removing effect begins 12 hours after use. The product is scented.

Instructions for use

Ready-to-use

Spray directly onto the cleaned surface, wipe and let dry. Do not rinse with water after cleaning.

Effect

Concentrate

Dosage: 20 ml / 1 l of water. Wipe wet the cleaned surface or spray the solution directly onto the cleaned surface. Let it dry. Do not rinse with water after cleaning. Severe target: Dosage: 100 ml / 1 l of water. Repeat if necessary.

Note

Do not use with strongly alkaline, strongly acid or disinfectants products. Shake before use.

Composition

Ingredient **Bacterial spores** Eliminates odors. Lowers the surface tension and removes dirt. Anionic and non-ionic < 5 % surfactants Makes it pleasant to use the product. Fragrance Benzisothiazolinone Preservative Laurylamine Preservative Dipropylenediamine

Product pH

7.2 neutral

Solution pH

7.2 neutral

Storage

Store in a warm place

Appearance and scent

A coloured, scented liquid.

9/2022 Page 2/2

User and environmental safety

Avoid unnecessary contact with skin. Protective gloves are recommended in continuous use. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice if needed. For safety data sheet please see www.kiiltoclean.com or www.kiiltoclean.fi.

Package size / Product code

Sales unit	Product Code	GTIN	GTIN (sales unit)
9 x 750 ml	41046	6417964410464	6417964485141



Additional information

Check the updated version of a paper brochure on our website at www.kiilto.com or send an e-mail to our customer service at asiakaspalvelu@kiilto.com.